



RR #1 Site 10 Compartment 10, Slocan Park, B.C. V0G 2E0

RADON CONSULTING

RADON TESTING

RADON MITIGATION

Ph: 250-359-8044
Cell: 250-365-9865

www.irps.info

Fax: 250-359-8045
Email: paul@irps.info

Paul Muntak CRT # 201066 CRMT # 201067

HOW TO DEPLOY AN LST-OO OR LLT-OO E-PERM DEVICE

IMPORTANT: *DO NOT UNSCREW THE ELECTRET FROM THE BOTTOM – THIS WILL INVALIDATE THE TEST*****

- The LST-OO or LLT-OO will be in the “OFF” position when you receive it.
- To initiate the radon test, remove the metal clip that is securing the chamber in the “OFF” position (large hole on the flat slide is visible). Pull the slide until it stops at the other end of the slide. This is now the “ON” position (large hole on flat slide is now not visible). Attach each, the metal clip and the wire tie in one of the small holes on each edge to secure the slide position (one on either side of the flat slide).
- Deploy the test in accordance with Health Canada deployment protocols.
- Record the Electret serial number (located on bottom of detector) along with your start date and time, as well as your name / address and location of the test.
- To terminate the test upon completion, remove the wire tie and the clip from the slide mechanism. Slide the slide through to the other end to the “OFF” position (large hole should now be visible on the flat slide). Insert the metal clip into one of the small holes on the edge of the flat slide. The chamber now will no longer measure radon.
- Record the end date and time that the device was turned to the “OFF” position.
- Return device along with a copy of your deployment information for analysis as soon as possible.



Small holes for metal clip and plastic wire tie

