



RR #1 Site 10 Compartment 10, Slocan Park, B.C. V0G 2E0

RADON CONSULTING

RADON TESTING

RADON MITIGATION

Ph: 250-359-8044
Cell: 250-365-9865

www.irps.info

Fax: 250-359-8045
Email: paul@irps.info

Paul Muntak CRT # 201066 CRMT # 201067

HOW TO DEPLOY SHORT TERM E-PERM DEVICES IN A TAMPER RESISTANT BOX

IMPORTANT: *DO NOT UNSCREW THE ELECTRET FROM THE BOTTOM –
THIS WILL INVALIDATE THE TEST*****

- The test device will be in the “OFF” position when you receive it.
- To initiate the radon test, open the box and unscrew both small caps on the tops of the E-Perm chambers. Gently allow the spring inside the chamber to push the “plunger” upwards (once it stops the device is now in the “ON” position).
- Secure the tamper resistant box by inserting the plastic wire tie through the small holes on the box.
- Deploy the test in accordance with Health Canada deployment protocols.
- Record the Electret serial numbers (located on bottom of detector) along with your start date and time, as well as your name / address and location of the test.
- To terminate the test upon completion. Cut off the plastic wire tie securing the tamper box lid. Gently push down on the plungers and screw both top caps back on to the chambers resulting in the “OFF” position.
- Record the end date and time that the device was turned to the “OFF” position.
- Return device along with a copy of your deployment information for analysis as soon as possible.

