



RR #1 Site 10 Compartment 10, Slocan Park, B.C. V0G 2E0

RADON CONSULTING

RADON TESTING

RADON MITIGATION

Ph: 250-359-8044
Cell: 250-365-9865

www.irps.info

Fax: 250-359-8045
Email: paul@irps.info

Paul Muntak CRT # 201066 CRMT # 201067

HOW TO DEPLOY A SHORT TERM E-PERM DEVICE

IMPORTANT: *DO NOT UNSCREW THE ELECTRET FROM THE BOTTOM – THIS WILL INVALIDATE THE TEST*****

- The test device will be in the “OFF” position when you receive it.
- To initiate the radon test, unscrew the small cap on the top of the E-Perm chamber. Gently allow the spring inside the chamber to push the “plunger” upwards (once it stops the device is now in the “ON” position).
- Deploy the test in accordance with Health Canada deployment protocols.
- Record the Electret serial number (located on bottom of detector) along with your start date and time, as well as your name / address and location of the test.
- To terminate the test upon completion. Gently push down on the plunger and screw the top cap back on to the chamber resulting in the “OFF” position.
- Record the end date and time that the device was turned to the “OFF” position.
- Return device along with a copy of your deployment information for analysis as soon as possible.

